

## ***elma spirol***

**READY-FOR-USE DEGREASING SOLVENT  
FOR BALANCE WHEELS AND HAIRSPRINGS**

### **Description**

Volatile degreasing chemical for the cleaning of metal precision parts, especially balance wheels and hairsprings of mechanical watches.

### **Application**

*elma spirol* is ready for use. Fill a small quantity of *elma spirol* in a suitable cleaning container, carefully close bottle. Immerse and move the parts to be cleaned in the chemical.

### **Hotline for application consulting**

Working days: Tel. ++49 (0) 7731 882-287. Email: [chemlab@elma-ultrasonic.com](mailto:chemlab@elma-ultrasonic.com)

### **Safety recommendations**

*elma spirol* is classified as hazardous according to the regulation (EC) No 1272/2008 [GHS] (highly flammable, aspiration toxicity, skin irritation, narcotic effect, hazardous to the aquatic environment - observe also with respect to this the hints indicated in the Safety Data Sheet and always handle chemicals with care).

### **Physical-chemical characterisation**

Density: 0,69 g/ml, flash point: - 14°C.

Mixture of hydrocarbons; does not contain halogens like chlorine or fluorine.

Ingredients according to Annex VII, A, EC-Regulation 648/2004 (detergents): >30% aliphatic hydrocarbons.

### **Disposal**

1. Disposal regulations same as for used oil / diesel / benzine.
2. Dispose via specialised disposal companies: European waste code: 14 06 03\*, „other solvents and solvent mixtures“.
3. Burn in suitable equipments, but according to official regulations.

Recommended for recycling or disposal: transport in appropriate suitable containers.

Do not discharge into the drains/surface waters/groundwater. Do not discharge into the subsoil/soil. Do not discharge product unmonitored into the environment.

### **Volumes, storage and transport**

Available volumes: 1 l.

Keep in tightly closed original container at a dry, cool and ventilated place and protected from heat and direct solar radiation. Do not store together with oxidizing agents. Do not mix with other chemicals. Keep away from ignition sources.

Shelf life: 2 years in original, unopened container from date of production (see stamp on label).

Classification for all means of transport: class 3, UN 3295.

**Elma Hans Schmidbauer GmbH&Co KG**

Kolpingstr. 1-7, D-78224 Singen

e-mail: [info@elma-ultrasonic.com](mailto:info@elma-ultrasonic.com)

11.03.11/ P:\Produkte\PRODInfo\Produkte\englisch\word\_GB\P\_spirol\_GB.doc

Tel.: ++49 (0) 7731 882-0

Fax: ++49 (0) 7731 882-266

[www.elma-ultrasonic.com](http://www.elma-ultrasonic.com)

